



ATR120 Wall Mounting Template

- 1) Choose location to mount clock:
 - indoor use only; 0° - 40°C (32° - 104°F)
 - avoid direct sunlight
 - avoid high humidity, dusty or chemical vapor environments
 - avoid walls subject to vibration or shock
- 2) Place template against wall. Make sure it is level.
Mark top screw 48" - 54" above floor using a pencil or pointed object.
Mark bottom screws.
- 3) Install (3) screws with each extending 1/4" from wall to top of screw.
- 4) Place clock mounting holes over screws and slide clock down until it stops. Clock should be firmly attached to wall.



06-0413-000 Rev. A



ATR120 Wall Mounting Template

- 1) Choose location to mount clock:
 - indoor use only; 0° - 40°C (32° - 104°F)
 - avoid direct sunlight
 - avoid high humidity, dusty or chemical vapor environments
 - avoid walls subject to vibration or shock
- 2) Place template against wall. Make sure it is level.
Mark top screw 48" - 54" above floor using a pencil or pointed object.
Mark bottom screws.
- 3) Install (3) screws with each extending 1/4" from wall to top of screw.
- 4) Place clock mounting holes over screws and slide clock down until it stops. Clock should be firmly attached to wall.



06-0413-000 Rev. A

