






# Remote RS 485 Lan (External Modem) Wiring Diagram

## RS-485 Serial Cables


Junction Box "Daisy Chain" Wiring Diagram



RS-485 Both lock "tabs" should be up or down when cable is stretched out.



NOTE: Connectors are shown from END VIEW. (As viewed from the outside of the connectors.)



WIRING DIAGRAM